


Montageanleitung
 Assembly instructions
 Instructions de montage
 Instrukcja montażu
 Instrucciones de montaje
 Montážní návod
 Istruzioni di assemblaggio



LCD 680

LCD 680 EW

37" - 70"
TV screen size



45 kg
max load

600x400
VESA max.

65 - 460 mm
Adjusted wall distance


+3°/-15°
Maximum TILT

120°
max SWIVEL




2A

Installez les supports adaptateurs
 Attaching the brackets to screen




1

Montage sur mur de béton
 Solid concrete mounting




2B

Accrochez le téléviseur sur la plaque murale
 Hang the TV on to the wall plate



1B

Montage sur mur à ossature de bois
 Wood stud mounting



-3~+15°

